Community Guide to In Situ Thermal Treatment



What Is In Situ Thermal Treatment?


In situ thermal treatment methods move or "mobilize" harmful chemicals in soil and groundwater using heat. The chemicals move through soil and groundwater toward wells where they are collected and piped to the ground surface to be treated using other cleanup methods. Some chemicals are destroyed underground during the heating process. Thermal treatment is described as "in situ" because the heat is applied underground directly to the contaminated area. The method is particularly useful for chemicals that do not dissolve readily in groundwater. Examples include solvents, petroleum and the wood preservative creosote.

How Does It Work?

In situ thermal treatment methods heat contaminated soil, and sometimes nearby groundwater, to high temperatures. The heat vaporizes (evaporates) the chemicals and water, changing them into gases. These gases, also referred to as "vapors," can move more easily through soil than liquids. High temperatures also can destroy some chemicals.

In situ thermal methods generate heat in different ways:

- Electrical resistance heating (ERH) delivers an electrical current between metal rods called "electrodes" installed underground. The heat generated from the movement of the current, as it meets resistance from soil, converts groundwater and water in soil into steam, vaporizing contaminants.
- Steam enhanced extraction (SEE) injects steam underground by pumping it through wells drilled in the contaminated area. The steam heats the area and vaporizes contaminants.
- Thermal conduction heating (TCH) uses heaters placed in underground steel pipes. TCH heats the contaminated area hot enough to vaporize and even destroy chemicals.



Example of an in situ thermal treatment system.

Wells pull the chemical and water vapors to the ground surface for aboveground treatment using one of several cleanup methods available. (See *Community Guide to Soil Vapor Extraction and Air Sparging* for how this is done.) If concentrations are high, the chemical vapors can be condensed back to liquid and reused.

How Long Will It Take?

In situ thermal treatment might take a few months to a few years to clean up a site. The cleanup time will depend on several factors that vary from site to site. For example, in situ thermal treatment will take longer where:

- Contaminant concentrations are high.
- The contaminated area is large or deep.
- The soil has a lot of organic matter, which causes chemicals to stick to the soil and not evaporate easily.

Are In Situ Thermal Treatment Methods Safe?

In situ thermal treatment methods do not pose a threat to site workers or the community when properly operated. For instance, when using ERH, the electrical current is prevented from traveling outside of the treatment area or to aboveground structures by using common electrical grounding techniques. A thermal treatment area is usually covered with an impermeable surface cover (such as concrete, asphalt or a heavy-duty tarp) to keep the heat and steam underground. Such seals also help prevent the release of chemical vapors to the air. In addition, workers test air samples to make sure that vapors are being captured.

How Might It Affect Me?

You might see or hear drilling equipment and other heavy machinery used to install wells or electrodes and to collect and treat vapors. You may see increased truck traffic as the equipment is delivered and later removed.

Why Use In Situ Thermal Treatment?

In situ thermal treatment methods speed the cleanup of many types of chemicals and are among the few in situ methods that can clean up chemicals that don't dissolve readily in groundwater. Thermal treatment can be used in silty or clayey soil where other cleanup methods do not perform well. It also can reach contamination deep underground or beneath buildings, which would otherwise be difficult or costly to dig up to treat above ground. In situ thermal treatment has been selected for use at dozens of Superfund sites and other cleanup sites across the country.



Ground Cover

ERH system cleans up contaminated soil and groundwater.

NOTE: This fact sheet is intended solely as general information to the public. It is not intended, nor can it be relied upon, to create any rights enforceable by any party in litigation with the United States, or to endorse the use of products or services provided by specific vendors.

Example

SEE was used to speed cleanup of the Southern California Edison Co., Visalia Pole Yard Superfund site in California. Use of chemicals to treat wooden utility poles contaminated soil and groundwater at the facility. Conventional "pump and treat" began in 1984 but did not show much progress in meeting cleanup objectives. In 1997, 14 steam injection wells were installed around the contaminated area. Steam was injected into the ground at depths of 80 to 100 feet, vaporizing the chemicals and forcing them toward the collection wells.

Initially, about 13,000 pounds of contaminants were pumped from the collection wells every day. SEE was stopped after three years when the wells began collecting less than 4 pounds per day, indicating that most of the chemicals had been removed. The pump and treat system was turned off in 2004. Overall, about 1.3 million pounds of contaminants were removed, and groundwater contaminant concentrations were reduced to meet drinking water standards. By using SEE as part of the cleanup effort. the overall site cleanup was reduced from an estimated 120 years to 20 years.

For More Information

- About this and other technologies in the Community Guide Series, visit: <u>https://clu-in.org/cguides</u> or <u>https://clu-in.org/</u> remediation/
- About use of cleanup technologies at a Superfund site in your community, contact the site's community involvement coordinator or remedial project manager. Select the site name from the list or map at <u>http://</u> <u>www.epa.gov/superfund/sites</u> to view their contact information.

Office of Land and Emergency Management (5203P) | EPA-542-F-21-016 | 2021 | www.clu-in.org